

User Guide

Keypad – Open Version

Release 1.01



1 – Introduction



AiM Keypad Open Version is the new range of compact expansions based on the CAN bus. It is available in different versions according to the number of pushbuttons whose status is transmitted through the CAN bus. Both buttons and CAN messages are fully configurable through the USB connection using AiM RaceStudio 3 Software.

Each button can be set as:

- **Momentary:** the pushbutton status is ON when the pushbutton is pushed
- **Toggle:** the pushbutton status changes from ON to OFF each time the pushbutton is pushed
- **Multistate:** the pushbutton value changes from 0 to a max value each time the pushbutton is pushed.

Furthermore, you can define a time threshold for each button that defines different behaviours when a SHORT or LONG compression event is detected.

Each pushbutton can be customised in a different colour or in solid, slow or fast blinking mode.

It is also possible to define a CAN INPUT protocol to allow the LED colour not only to acknowledge a button compression event, but also to show the status of a device.

Finally, it is possible to configure a pushbutton for increasing or decreasing the brightness level of the keypad.

	K6 Open	K8 Open	K15 Open
Buttons	6 programmable	8 programmable	15 programmable
Backlight	RGB with Dimming option		
Connection	USB through 7 pins Binder 712 female connector		
Body Material	Rubber silicon and reinforced PA6 GS30%		
Dimensions	97.4x71x4x24mm	127.4x71.4x24	157.4x104.4x24
Weight	120g	150g	250g
Waterproof	IP67		



2 – Available kits optional and spare parts

Keypad open version available kits are:

Keypad K6 Open

- Keypad K6 Open + 200 cm AiM CAN cable
- Keypad K6 Open + 400 cm AiM CAN cable

X08KPK6OC200
X08KPK6OC400

Keypad K8 Open

- Keypad K6+ 200 cm AiM CAN cable
- Keypad K6+ 400 cm AiM CAN cable

X08KPK8OC200
X08KPK8OC400

Keypad K15 Open

- Keypad K15 Open + 200 cm AiM CAN cable
- Keypad K15 Open + 400 cm AiM CAN cable

X08KPK15OC200
X08KPK15OC400

All Keypads open version come with an **Open CAN cable** used to connect it to the master device but cables can also be bought separately as spare parts. The related part numbers are:

- 200 cm open CAN cable
- 400 cm open CAN cable

V02551770
V02551780

All Keypads open version can also be connected to an **AiM open CAN cable** that can be bought separately as optional. The related part numbers are:

- 200 cm open AiM CAN cable
- 400 cm open AiM CAN cable

V02551850
V02551860

To connect Keypad open version to the PC a proper **optional USB cable** is necessary. The related part numbers are:

- 30 cm USB cable
- 50 cm USB cable+12V power

V02551690
V02551960

Buttons icons:

- 72 pieces icon kit
- single icon

X08KPK8KICONS

[click here to know each icon part number](#)

3 – Software configuration


For configuring the Keypad, download RaceStudio3 software from AiM website at aim-sportline.com **Software/firmware download area:** [AiM - Software/Firmware download \(aim-sportline.com\)](https://aim-sportline.com)

Once the software is installed, run it and follow these steps:

- Enter **Configuration Menu** clicking the icon highlighted below:



- press **"New"** button (1) on the top right toolbar
- scroll the panel that is prompted, select the desired Keypad Open (2)
- press **"OK"** (3)



You need to configure:

- Buttons
- CAN Input protocol
- CAN Output messages

3.1 – Pushbuttons configuration

Some quick notes before we start analysing how to configure the Keypad:

- the pushbutton's status can be set as **Momentary**, **Toggle** or **Multi-status** as explained in paragraph 3.1.1; it is also possible to set a time threshold to manage short and long button pressures in different ways
- the pushbutton status can be transmitted through CAN at a fixed frequency and/or when it changes
- the status of each pushbutton at power OFF can be restored at the following power ON
- each pushbutton can be customized – solid or blinking – in 8 different colours as explained in paragraph 3.1.2
- open Keypads can manage a CAN INPUT protocol in order to give feedback through the LEDs colour, based on the information it receives.


3.1.1 – Pushbuttons status configuration

You may set different modes for every pushbutton:

MOMENTARY: the status is:

- ON when the pushbutton is pushed
- OFF when the pushbutton is released

Please note: both status ON and OFF can be freely associated with a numeric value



Please note: only setting the pushbutton as Momentary you can associate the following command to each pushbutton:


"Device Brightness" command

- Increase
- Decrease

TOGGLE: the status is:

- ON when the button is pushed once, and it remains ON till when is pushed again
- OFF when the button is pushed the second time

Both status ON and OFF can be freely associated with a numeric value.



MULTI-STATUS: the status may assume different values that change every time the pushbutton is pushed. This setting is useful, for example, to select one among different maps or to set different suspension levels etc.


Name:

WorkAs: ☐ Momentary ☐ Toggle ☒ Multistatus ☐ Restore last status at power on

☐ Use timing Time threshold between short and long status: sec

Position	Label	Value	Short Press leads to	Long Press leads to	
0	<input type="text" value="OFF"/>	<input type="text" value="0"/>	ON	LONG	[+] [-]
1	<input type="text" value="ON"/>	<input type="text" value="1"/>	LONG	OFF	[+] [-]
2	<input type="text" value="LONG"/>	<input type="text" value="2"/>	OFF	ON	[+] [-]

MULTISTATUS





0 1 2 ... n 0

Push button status

Push button position

No matter the mode the pushbutton is set you can also set a time threshold: in this case, the pushbutton is set at two different values that you may define, depending on how long you push it.

SETTING WITH TIME THRESHOLD



To do so, enable the “**use timing**” checkbox on the top box of the setting panels. In this case, the pushbutton is set at two different values that you may define according to how long you push it.

Name: OK8 Button 2

WorkAs: ☒ Momentary ☐ Toggle ☐ Multistatus ☐ Restore last status at power on

☒ Use timing Time threshold between short and long status sec: 0.5

Rest Status		Active Status		Long Status	
Label	Value	Label	Value	Label	Value
OFF	0	ON	1	LONG	2

Set Command Set Command

Name: OK8 Button 1

WorkAs: ☐ Momentary ☒ Toggle ☐ Multistatus ☐ Restore last status at power on

☒ Use timing Time threshold between short and long status sec: 0.5

Rest Status		Short Status		Long Status	
Label	Value	Label	Value	Label	Value
OFF	0	ON	1	LONG	2

Name: OK8 Button 1

WorkAs: ☐ Momentary ☐ Toggle ☒ Multistatus ☐ Restore last status at power on

☒ Use timing Time threshold between short and long status sec: 0.5

Position	Label	Value	Short Press leads to	Long Press leads to	
0	OFF	0	ON	LONG	[+] [-]
1	ON	1	LONG	OFF	[+] [-]
2	LONG	2	OFF	ON	[+] [-]

3.1.2 – Pushbutton colour configuration

Each pushbutton can be set with different colours to indicate the action performed by the driver and the feedback of that action: the pushbutton may be turned – for example – blinking (slow or fast) GREEN to show that the pushbutton has been pushed, and solid GREEN when the action is activated.

LED Configuration

Set Color

Green

continuously

when following condition is

verified

for at least

0

sec

priority

Button 2 equal to ON

Add

Condition

☐ Always TRUE
☐ Always FALSE

☒ Button 2

equal to

constant

ON

TRUE after a time of 0 sec in which it is verified
FALSE after a time of 0 sec in which it is no longer verified

OK

Cancel

Set Color

Green

slow blinking

when following condition is

verified

for at least

0

sec

Button 2 equal to ON

Add


3.2 – CAN communications

It is possible to configure the CAN Output messages, used for transmitting the status of the pushbuttons, as well as the CAN Input messages, used for receiving feedback from the field entering the related tabs shown here below.




3.2.1 – CAN Input messages configuration

The CAN input protocol is a bit more complex to manage: the Keypad is supposed to be connected to a CAN network where more devices share their status and channels. This information can be read to give the driver the accurate status of the device that a pushbutton relates to in order to activate it. To read the CAN messages, you may select the proper protocol if available in the protocol list. In case the protocol needed is not included it is possible to configure a custom protocol using the **CAN Driver Builder**. Please refer to the proper documentation you find at this [link](#) for further information.



3.2.2 – CAN Output messages configuration

Open Keypad can send all relevant messages and each message can be transmitted at a fixed frequency or whenever there is a change in the fields transmitted. You can, for example, transmit a message every time a pushbutton changes status and/or every second.



The dialog box titled "Set CAN Header Details" contains the following fields and controls:

- ID CAN (hex):** A text input field containing "0x0".
- Bit Length:** Two radio buttons labeled "11 bits" (selected) and "29 bits".
- DLC:** A dropdown menu showing "8 bytes".
- Byte Order:** A dropdown menu showing "Little Endian".
- Frequency:** A dropdown menu showing "... .. disabled".
- Transmit when the value changes:** A checkbox that is currently unchecked.
- Buttons:** "OK" and "Cancel" buttons at the bottom right.


Please refer to the following document for CAN Message information:

[FAQ_RS3_CAN-Output_100_eng.pdf \(aim-sportline.com\)](#)


4 – Technical drawings

The following images show keypad and cables dimensions and pinout-


Keypad open K6 dimensions in mm [inches]




Keypad open K6 pinout



Keypad K8 dimensions in mm [inches]:




Keypad K8 pinout:






Keypad K15 dimensions in mm [inches]:




Keypad K15 pinout:





CAN Open cable pinout:



USB Cable pinout:

